


Menu Map

NOTE: This map depicts the menu structure for an FXR-class inverter. Other inverter classes may have a slightly different menu structure and selections.



MATE3s System Display and Controller Menu Map



Worldwide Corporate Offices			
Headquarter Germany Hansastrasse 8 D-91126 Schwabach Tel: +49 9122 79889 0 Fax: +49 9122 79889 21 Mail: info@alpha-outback-energy.com	Eastern Europe ee@alpha-outback-energy.com Middle East me@alpha-outback-energy.com	France and Benelux fbnl@alpha-outback-energy.com Spain spain@alpha-outback-energy.com	Russia russia@alpha-outback-energy.com Africa africa@alpha-outback-energy.com

Alpha and Outback Energy GmbH reserves the right to make changes to the products and information contained in this document without notice. Copyright © 2020 Alpha and Outback Energy GmbH. All Rights reserved.

For more information please visit www.alpha-outback-energy.com